



No.	Part name	Qty.
1	right buckle	1
2	self-tapping screw	13
3	self-tapping screw	3
4	Pan head Phillips screw	2
5	right housing	1
6	spingdle circlip	1
7	gear box cover	1
8	deep groove ball bearing	2
9	big gear	1
10	gear box	1
11	deep groove ball bearing	1
12	rotor	1
13	stator screw	2
14	spring washer	2
15	flat gasket	2
16	stator	1
17	hex thicken nut	2
18	deep groove ball bearing	1
19	motor rear bracket	1
20	wind leaf	1
21	lock nut	1
22	copper sleeve	2
23	carbon brush	2
24	self-tapping screw	2
25	power cord hook	1
26	torsional spring	1
24	fixed pin	1
28	left housing	1
29	left buckle	1
30	power cord	1
31	cable sheath	1
32	inductor	2
33	capacitor	1
34	self-tapping screw	4
35	press board	3
36	Pan head Phillips screw	4
37	self-tapping screw	4
38	right handle 2	1
39	right handle tube	1
40	right handle 1	1
41	hex nut	4
42	switch	1
43	cable	1
44	rear iron pipe	1
45	hex nut	5
46	lifting ring fixing ring	1

47	hexagon socket head screw	1
48	lifting ring	1
49	left handle 2	1
50	left handle tube	1
51	left handle 1	1
52	hexagon socket head screw	6
53	6mm spring cushion	6
54	handle holder	1
55	sponge tube	1
56	knob	1
57	flat gasket	4
58	locking sleeve	1
59	Oiling bearing	8
60	rear hard shaft	1
61	front hard shaft	1
62	internal tooth lock washer	1
63	spring leaf	1
64	front iron pipe	1
65	cylinder head hexagon socket three-combination screw	2
66	open core blind rivet	1
67	guard press board	1
68	guard	1
69	guard blade	1
70	bear box assembly	1
71	hexagon socket head screw	1
72	hexagon socket head screw	1
73	3T blade	1
74	cross socket wrench	1
75	5mm Allen wrench	1
76	Allen wrench	1
77	thermowell	1
78	self-winding rope	1
79	strap	1
80	soft start	1